


PINDICATORS



WARNING: By reading this document, I agree it is only to be used as an educational guide. Morimoto Lighting makes no guarantee on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. Use at your own risk. If you are unable to clearly understand and adapt the information below, professional installation is recommended.



Mounting

Panel

The Pindicator can be mounted through

panels up to 15mm in thickness. Insert

the indicator into the desired location, add one washer and then the nut.