



THE AUTOMOTIVE LIGHTING BENCHMARK

INSTALL GUIDE

PERMATRATOR SEALANT SOLVENT

WARNING: By reading this document, you agree it is only to be used as an educational guide. Morimoto Lighting nor its distributors make guarantees on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. Use at your own risk. If you are unable to clearly understand and adapt the information below, professional installation is recommended.

WARNING: PERMATRATOR IS A SOLVENT. IT CAN CAUSE IRRITATION AND INJURIES. USE WITH CAUTION. PROTECTIVE EQUIPMENT IS STRONGLY RECOMMENDED PRIOR TO USE!

PACKAGE CONTENTS



1X SOLVENT BOTTLE



1X 100MM SYRINGE

USING PERMATRATOR

Permatrator sealant should be drawn into syringe slowly, then injected liberally into the headlight's existing hard seal (aka "permaseal"). It will not on its own eat through the sealant, but helps it break down and lose adhesion with the housing plastics. We recommend using Permatrator in addition with standard housing opening methods for effective use.

